



68060メモリマップ

0x00000000	X68000本体メモリ
0x00FFFFFF	
0x10000000	DDR-RAM
0x1F200000	ColdFire共有DDR-RAM
0x1FFFFFFF	
0xF0000000	FLASHROM
0xF0600000	ColdFire共有FLASHROM
0xF07FFFFFFF	

ColdFireメモリマップ

0x00000000	ColdFire内蔵SRAM
0x0000FFFF	
0x10000000	SD-RAM
0x11FFFFFF	
0x80000000	X68000本体メモリ (CS1)
0x80FFFFFF	
0xA0000000	Boot FLASHROM(CS0)
0xA0200000	共有DDR-RAM(CS0)
0xA0FFFFFF	